

# CC200

*Catheter Cabinet*



CC200

# CathCabinet

## A Catheter Cabinet Customized to Individual Department Needs

The **CC200 Cath Cabinet** is a hospital-grade cabinet optimized for the functional storage of catheters in cardiac cath labs, invasive radiology suites, and the operating room environment.

Durable heavy gauge welded steel and high quality ball-bearing drawer slides, assure long-lasting, trouble-free use. Clear locking pocket doors provide for catheter security, create an ideal dust-free environment for storage, and fully retract for full access to cabinet contents. Inside the cabinet can be customized to meet the requirements of individual departments. The cabinet has the option of drawers, bins, shelves, and hook-slides in multiple locations.

Catheters are stored on mobile hooks attached to an easy-gliding ball-bearing slide, allowing non-obstructed access to all catheters in the cabinet. With multiple slides at different levels, cabinet capacity is maximized.

Drawers are steel-constructed and feature an integrated pull latch. Each drawer is mounted on full extension, high quality ball-bearing drawer slides for extra-smooth motion when fully loaded. The 5" drawer depth is ideal for boxed catheters/wires, or other items awkward to hang. A variety of drawer widths are manufactured to fit the different cabinet configurations. Drawers can be ordered with optional locks for additional security.

Pharmaceuticals, contrast media, syringes and other small items can be stored in individual plastic bins. (A full line of mobile carts, including transfer carts to transport cassettes to the pharmacy or central supply for restocking, are also available from S&S).

Part No.	Description	Notes	Part No.	Description	Notes
CC200	Catheter Cabinet	Catheter cabinet with pocket doors	CC200-50-1L	Half Drawer w/ Lock	
755009	Hook Slides		CC200-50-2L	One Third Drawer w/ Lock	
CC200D	Vertical Divider		CC200-50-3L	Two Thirds Drawer w/ Lock	
CC200S1	Full Width Shelf	Shelves are also available with fixed vertical partitions.	CC200-20	5.5" Cassettes	Contains six 5.5" individual bins.
CC200S2	Half Shelf	Shelves are also available with fixed vertical partitions.	CC200-30	8.25" Cassettes	Contains four 8.25" individual bins.
CC200S3	One Third Shelf	Shelves are also available with fixed vertical partitions.	CC200-40	8.25" and 5.5" Cassette	Contains two 8.25" individual bins and three 5.5" individual bins
CC200S4	Two Thirds Shelf	Shelves are also available with fixed vertical partitions.	CC200-20D	5.5" Bin Dividers	100 per package
CC200-50	Full Drawer		CC200-40D	8.25" Bin Dividers	100 per package
CC200-50-1	Half Drawer		CC200-20DL	Long Interlocking Divider	Lengthwise dividers for 5.5" and 8.25" bins; 10 per package
CC200-50-2	One Third Drawer		CC200-20DW	Wide Interlocking Divider, 5.5"	Widthwise dividers for 5.5" bins; 10 per package
CC200-50-3	Two Thirds Drawer		CC200-40DW	Wide Interlocking Divider, 8.25"	Widthwise dividers for 8.25" bins; 10 per package
CC200-50L	Full Drawer w/ Lock				

**Dimensions (HxWxD):** 78" x 43" x 19-1/2"

*NOTE: Assembly Required. An 18-inch clearance in front of the cabinet is required to swing open the doors and slide into the door pockets.*



Technology

10625 Telge Road, Houston, TX 77095  
 800-231-1747 281-815-1300 Fax 281-815-1494  
[salesupport@radx.com](mailto:salesupport@radx.com) [www.ssxray.com](http://www.ssxray.com)